

RELOOP MIXTOUR - VIRTUALDJ MAPPING

BUTTON	NORMAL ACTION	SHIFT ACTION
Transport Mode		
T mode button	Hold + BROWSE_ENC to seek song +/-	Smart Play on/off
PLAY	Play/Pause	Goes at the beginning of the track
CUE	Cue/Stop	Beat Tap If track is paused and pressed once, it sets the current position as Beatgrid anchor. If track is playing adjusts tempo if pressed repeatedly on tempo (for more than 4 times)
SYNC	Sync (Long press : Pitch Reset)	Doubles Loop Size
LOOP	Loop On/Off	Halves Loop size
Cue mode (orange LEDs)		
C mode button	Select Sampler mode	Smart Cue on/off
C1	Hotcue 1	Delete Hotcue 1
C2	Hotcue 2	Delete Hotcue 2
C3	Hotcue 3	Delete Hotcue 3
C4	Hotcue 4	Delete Hotcue 4
Sampler mode (Yellow LEDs)		
C mode button	Select Cue mode button	Load next Sampler Bank
C1	Sampler 1	Sampler Stop 1
C2	Sampler 2	Sampler Stop 2
C3	Sampler 3	Sampler Stop 3
C4	Sampler 4	Sampler Stop 4
FILTER / EFFECTS		
FX	Activate Effect (On/Off)	Select next Effect
FILTER KNOB (mapping A)	Adjust Low-High Pass Filter . If Effect is active adjust 1st Parameter (FILTER FX COMBO)	Adjust 2nd FX-Parameter
FILTER KNOB (mapping B)	Adjust Low-High Pass Filter	Adjust 1st FX-Parameter
OTHERS		
BROWSE ENCODER	Scroll through files or folders	When Prelisten Player is active, seeks +/- Prelisten Player
BROWSE PUSH	Set focus to Songs/Tracks List	Adds the selected track to the Automix List
BACK	Set focus to Folders list . If focus is on Folders list, open/close sub-folders	Set focus to Sideview
LOAD	Load selected track to deck Hold for more than 2 seconds to unload	Left LOAD : Cycle Sideview Lists Right LOAD : Cycle Center Mixer Panels
PFL	Send deck to Headphones channel	Start/Stop Prelisten Player (Prelisten Player in INFO Browser window)
VOLUME	Volume Faders	Volume + PLAY from 0->up + CUE from up->0