




MARK[®]




FLM 200


User Manual / Instrucciones de Usuario

Rev 14.02.01

Our DMX indoor **FLM 200** (2x4 sections) offers many possibilities to achieve the effects which you want. The rolling and chasing effects are very good. It is designed for the stages, disco, night clubs etc, even the building halls. Please read the manual before operation.




The picture for the rear panel:



1. Weight: 3.5kg
2. Size: 380*240*100mm
3. Power input: AC180-250V/50-60Hz
AC90-130V/50-60Hz
4. Wattage: 200W
5. LEDs: 384pcs White
6. Beam angle: 120 degree
7. 3 pin female XLR socket and 3 pin male XLR socket
8. 3 pin XLR power in and power out
9. Linkable via 3-pin XLR cable
10. Built-in microphone
11. Black aluminum material(white housing optional)
12. Working place: indoor, temperature:-20℃~45℃, humidity:0%-90%
13. LED display for easier operation
14. Built-in programs, stand alone, DMX mode, music active, static color
15. 3 selectable DMX modes: 2.4.9 DMX channels mode

LED DISPLAY FUNCTIONS



P--1 ⇒ 2 DMX channels *F500~F520* ⇒ Strobe speed *A000~A100* ⇒ Loop frequency
P--2 ⇒ 4 DMX channels *SP00~SP20* ⇒ Effect speed
P--3 ⇒ 9 DMX channels *E000~E255* ⇒ Dimmer

1. Press "mode" to choose working mode
2. Press "setup" to set parameter
3. Press "up" or "down" to change number value

DMX value as follows:

DMX mode (P--1)

CH1	CH2
WHITE	0=OFF
0-255 dimming	1-255 flash


DMX mode (P--2)

CH1	CH2	CH3						CH4
dimmer		NO.	DMX value	FUNCTION	NO.	DMX value	FUNCTION	
0-255 Light 0=OFF	1-255 flash 0=OFF	1	0	OFF	15	130-139	PROGRAM15	SPEED 0-255
		2	1-9	PROGRAM01	16	140-149	PROGRAM16	
		3	10-19	PROGRAM02	17	150-159	PROGRAM17	
		4	20-29	PROGRAM03	18	160-169	PROGRAM18	
		5	30-39	PROGRAM04	19	170-179	PROGRAM19	
		6	40-49	PROGRAM05	20	180-189	PROGRAM20	
		7	50-59	PROGRAM06	21	190-199	PROGRAM21	
		8	60-69	PROGRAM07	22	200-209	PROGRAM22	
		9	70-79	PROGRAM08	23	210-219	PROGRAM23	
		10	80-89	PROGRAM09	24	220-229	PROGRAM24	
		11	90-99	PROGRAM10	25	230-239	PROGRAM25	
		12	100-109	PROGRAM12	26	240-249	Sound Mode 1	
		13	110-119	PROGRAM13	27	250-255	Sound Mode 2	
		14	120-129	PROGRAM14				


DMX mode (P--3)

CH1	CH2	CH3	CH4	CH5
flash	1	2	3	4
1-255 Light 0=OFF	0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming
CH6	CH7	CH8	CH9	
5	6	7	8	
0-255 dimming	0-255 dimming	0-255 dimming	0-255 dimming	

Nuestro flash con LED para aplicaciones de interior FLM 200 (2 x 4 secciones) ofrece muchas posibilidades para conseguir el efecto deseado. Dispone de efectos de giro y chasing. Ha sido diseñado para escenarios, discotecas, clubs e incluso salas de reunión, etc. Por favor, lea el manual cuidadosamente.




Panel Trasero:



1. Peso: 3.5kg
2. Dimensiones: 380*240*100mm
3. Alimentación: AC180-250V/50-60Hz
AC90-130V/50-60Hz
4. Potencia: 200W
5. LEDs: 384 piezas, Blanco
6. Angulo del haz: 120°
7. XLR hembra de 3 pines- XLR macho de 3 pines
8. XLR 3 pines entrada / link DMX
9. Linkable via cable DMX 3 pin
10. Micrófono incorporado
11. Aluminio color negro
12. Ubicación: interior, temperatura: -20°C~45°C, humedad: 0%-90%
13. Display LED para una rápida configuración
14. Programas incorporados, stand alone, modo DMX, audio y colores estáticos
15. 3 modos DMX seleccionables: 2, 4 y 9 canales DMX

FUNCIONES DEL DISPLAY



P--1 ⇒ 2 canales DMX *F500~F520* ⇒ Veloc. strobo *A000~A100* ⇒ freq. de loop
P--2 ⇒ 4 canales DMX *SP00~SP20* ⇒ veloc. efecto
P--3 ⇒ 9 canales DMX *E000~E255* ⇒ Dimmer

1. Presione "mode" para elegir el modo de trabajo
2. Presione "setup" para configurar el parámetro
3. Presione "up" o "down" para cambiar el valor

Los valores DMX son los siguientes:

DMX mode (P--1)

CH1	CH2
BLANCO	0=OFF
0-255 dimming	1-255 flash

DMX mode (P--2)

CH1	CH2	CH3						CH4
dimmer		NO.	Valor DMX	FUNCION	NO.	Valor DMX	FUNCION	
0-255 dimmer 0=OFF	1-255 flash 0=OFF	1	0	OFF	15	130-139	PROGRAM15	SPEED 0-255
		2	1-9	PROGRAM01	16	140-149	PROGRAM16	
		3	10-19	PROGRAM02	17	150-159	PROGRAM17	
		4	20-29	PROGRAM03	18	160-169	PROGRAM18	
		5	30-39	PROGRAM04	19	170-179	PROGRAM19	
		6	40-49	PROGRAM05	20	180-189	PROGRAM20	
		7	50-59	PROGRAM06	21	190-199	PROGRAM21	
		8	60-69	PROGRAM07	22	200-209	PROGRAM22	
		9	70-79	PROGRAM08	23	210-219	PROGRAM23	
		10	80-89	PROGRAM09	24	220-229	PROGRAM24	
		11	90-99	PROGRAM10	25	230-239	PROGRAM25	
		12	100-109	PROGRAM12	26	240-249	Sound Mode 1	
		13	110-119	PROGRAM13	27	250-255	Sound Mode 2	
		14	120-129	PROGRAM14				

DMX mode (P--3)

CH1	CH2	CH3	CH4	CH5
flash	1	2	3	4
1-255 dimmer 0=OFF	0-255 dimmer	0-255 dimmer	0-255 dimmer	0-255 dimmer
CH6	CH7	CH8	CH9	
5	6	7	8	
0-255 dimmer	0-255 dimmer	0-255 dimmer	0-255 dimmer	

EQUIPSON, S.A.

**Avda. El Saler, 14 - Pol. Ind. L'Alteró
46460 - Silla (Valencia) Spain**

**Tel. +34 96 121 63 01 Fax + 34 96 120 02 42
www.equipson.es / equipson@equipson.es**