

# IMPORTANT - PLEASE READ

## Terms and Conditions of End-User License Agreement

The software upgrade program for Denon SC3900 model provided herewith (the "Software") is proprietary to D&M PROFESSIONAL, a division of D&M Holdings US Inc. ("D&M PRO") and has been made available to you only in accordance with and subject to the terms and conditions of this License Agreement. By installing or using the Software, you will be confirming your acceptance of the Software and your agreement to be bound by all of the following terms and conditions, including, without limitation, the disclaimers which are a part hereof: IF YOU DO NOT AGREE TO THE FOLLOWING TERMS AND CONDITIONS DO NOT INSTALL OR USE THE SOFTWARE.

1. **Title.**  
The Software is the property of D&M PRO. No title or ownership therein or thereto is transferred to you hereunder. This License only provides you with certain prescribed rights to use the Software, subject always to the terms and conditions herein set forth. All rights in and to the Software are reserved by D&M PRO.
2. **Limited Rights of Use.**  
This License only allows you to use the Software for your own internal purposes and solely in connection with a Denon SC3900 player that you personally own (the "Product"). The Software is licensed not sold. All rights not specifically granted to you hereunder are retained exclusively by D&M PRO.
3. **Non-Disclosure.**  
You acknowledge that the Software is proprietary to and a trade secret of D&M PRO, and you agree not to make or distribute copies of the Software or to transfer the Software electronically or otherwise to any other person. The Software is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. Without limiting the generality of the foregoing, you also agree:
  - (a) Not to transfer the Software from one computer to another or over a network.
  - (b) Not to decompile, reverse engineer, disassemble or modify the Software in any way or for any purpose.
  - (c) Not to resell, rent or otherwise transfer the Software to any other person.
  - (d) Not to create or distribute any derivative works based upon the Software or any part thereof.
  - (e) Not to use the Software in any other machine other than the model intended.
4. **Limited Warranty.**  
The Software has been provided to you free of charge and "AS IS" with all faults; provided, that, D&M PRO's Limited Warranty shall continue to apply with respect to the Product after installation of the Software, subject to all of the terms and conditions of such Limited Warranty, including its duration based on the original date of purchase of the Product. **D&M PRO makes no other warranty of any kind, express or implied, including, without limitation, any implied warranty of merchantability or fitness for particular purpose, non-infringement or otherwise with respect to the Software or the Product.** Without limiting the generality of the foregoing:
  - (a) D&M PRO assumes no responsibility for and shall have no liability of any kind with respect to any problems encountered in conjunction with or arising out of the downloading of the Software, including, without limitation, problems resulting from any interruption that may have occurred while downloading the Software.
  - (b) Neither D&M PRO nor any of its distributor's suppliers or other vendors shall be required to provide you with any technical support or services of any kind relating to the Software.
5. **No Consequential Damages.**  
Except as may be prohibited by law, Neither D&M PRO nor any of its distributors shall be liable for any indirect, special, incidental or consequential damages or losses of any kind incurred or arising out of or in connection with your downloading or use of the Software.
6. **Hold Harmless and Limit of Liability.**  
You agree to release and hold harmless D&M PRO and its distributors of and from any and all claims, demands, suits, proceedings, losses, damages, liabilities, costs and expenses (including attorneys' fees and disbursements) of any kind arising out of or relating to the Software or its use. EXCEPT AS MAY BE PROHIBITED BY LAW, IN NO EVENT WILL D&M PRO OR ITS SUPPLIERS BE LIABLE TO YOU FOR ANY AMOUNT ABOVE FIFTY DOLLARS (\$50.00).
7. **Governing Law.**  
The terms and conditions of this License Agreement shall be governed by and construed in accordance with the law of the State of New York. Any claims, actions or proceedings relating to this License Agreement or the enforcement hereof shall be brought in the courts of the State of New York or Federal courts located in New York, NY, and you waive any objection to the jurisdiction of such courts.
8. **Entire Agreement.**  
The terms and conditions herein set forth constitute the entire agreement between you and D&M PRO with respect to the subject matter hereof, and all agreements, commitments, undertakings, understandings or statements of any kind previously made by D&M PRO or any of its distributors with respect to the subject matter hereof are merged herein and superseded by this License Agreement. No amendment or modification of the terms of this License Agreement shall be effective or binding on D&M PRO unless it is made in writing and executed or published by D&M PRO. References to "D&M PRO" herein include D&M Holdings US Inc. its subsidiaries and affiliates.

D&M Professional, All Rights Reserved, Copyright 2012

## SC3900 Mapping File for SERATO SCRATCH LIVE

Before using SC3900, install the DJ software (SERATO SCRATCH LIVE) in your computer to which SC3900 is connected. After the installation, install the mapping file for operating SERATO SCRATCH LIVE with SC3900 **Hybrid MIDI mode**.

The method of installation for the mapping file.

1. Download the mapping file.  
From the Denon DJ Website ([www.denondj.com](http://www.denondj.com)), access the Website for your region. There, download the following file from the SC3900 product page.  
SC3900\_MAP\_V1000\_SSL.xml

2. Copy the downloaded file to the following folder.  
[Windows]  
\\ MyDocuments \ MyMusic \ \_Serato\_ \ MIDI \  
[Macintosh]  
~ \Music \ \_Serato\_ \MIDI \

Note:


When there is not a MIDI folder, it's necessary to create a MIDI folder by the following operation.

[Windows]

- (1) Click "New folder"




- (2) Rename "New folder" to "MIDI"




[Macintosh]

- (1) Click File menu, and then click "New folder".



- (2) Rename "untitled folder" to "MIDI"



3. Loading the .XML file.
  - (1) Click "SETUP" on Scratch Live to open setup menu.
  - (2) Click "MIDI" to open MIDI panel.
  - (3) Select the file "SC3900\_MAP\_V1000\_SSL " and click "LOAD".
  - (4) Click "SETUP" to close the setup menu.

Note :

\* This mapping file has been confirmed and tested with Serato™ Scratch Live ver.2.2.

Please use the mapping file with Serato™ Scratch Live ver.2.2 or later.

\* Please switch to "REL"(Relative) mode if you use "ABS" or "INT" mode on Serato™ Scratch Live.

Regarding mapping file setting on Serato™ Scratch Live, please refer to their web site (<http://serato.com/>).


Serato™ is a trademark of Serato™ Audio Research.

Scratch Live is a registered trademark of Serato Audio Research.


## Rane/Serato Hardware Configuration

**SC3900:** Connect the analog RCA Outputs from each Deck into the Rane/Serato SL1, SL2, SL3, SL4 (TTM57SL, 61, 62, 68 mixers) "Line" Inputs (not Phono)  
Connect a USB cable from each Deck and Rane/Serato hardware to your computer, a total of 3 USB cables.

*\*Use a "powered USB HUB" if your computer or MAC does not have enough USB ports available. Connect both Decks to the HUB and Hub to computer.*



**Serato™ Scratch Live Functionality**  
(MIDI Channel: Left Deck=CH5, Right Deck=CH6)



	SC3900 CONTROLS	SCRATCH LIVE FUNCTIONALITY	CLR +	SHIFT +	SYNC+
A	CUE	Jump Temp Cue	-		Set Temp Cue
B	FAST SEARCH (RWD)	Rewind	-	-	
C	FAST SEARCH (FWD)	Fast Forward	-	-	
D	TRACK SEARCH (PREV)	Load Previous Track	-	-	
E	TRACK SEARCH (NEXT)	Load Next Track	-	-	
F	AUTO LOOP	Auto Loop Button	-	Loop Roll	
G	-	Auto Loop length (x1/2)	-	-	
H	+	Auto Loop length (x2)	-	-	
I	A	Loop In Button	-	-	
J	B	Loop Out Button	-	-	
K	EXIT/RELOOP	Reloop Button	-	-	
L	HOT CUE 1	Trigger Cue Point Button A0	Set Cue Point Button A0	Auto Loop 1/16 Button	
	HOT CUE 1 (MIDI BANK 2)	Play Sample Slot 1 / Slot 4	-	-	
M	HOT CUE 2	Trigger Cue Point Button A1	Set Cue Point Button A1	Auto Loop 1/8 Button	
	HOT CUE 2 (MIDI BANK 2)	Play Sample Slot 2 / Slot 5	-	-	
N	HOT CUE 3	Trigger Cue Point Button A2	Set Cue Point Button A2	Auto Loop 1/4 Button	
	HOT CUE 3 (MIDI BANK 2)	Play Sample Slot 3 / Slot 6	-	-	
O	HOT CUE 4	Trigger Cue Point Button A3	Set Cue Point Button A3	Auto Loop 1/2 Button	
	HOT CUE 4 (MIDI BANK 2)	-	-	-	
P	Hot List Add/Remove	Add Track to Prepare Panel	-	-	
Q	DUMP	Censor Button	-	-	
R	TAP	Tap Tempo	-	-	
S	KEY ADJUST	Key Lock	-	-	
T	SEL. knob	Select / Load Track to Deck	-	-	
U	BACK	Tab Focus	-	-	
V	Forward	-	-	-	
W	TIME	Open Files Panel	-	-	
X	DISPLAY	Open Browse Panel	-	-	
Y	SINGLE/CONT.	Open History Panel	-	-	
Z	MEMO	Open Prepare Panel	-	-	

	SC3900 CONTROLS	Platter FUNCTIONALITY	CLR +	SHIFT +	
a	Play/Pause	Playback and Pause	-	-	
b	REVERSE	Reverse Playback	-	-	
c	VINYL	Vinyl mode ON / OFF	-	-	
d	PITCH BEND [-]	Bend Down	-	-	
e	PITCH BEND [+]	Bend Up	-	-	
f	PITCH RANGE	Change Pitch Range	-	-	
g	START TIME	Adjust the Track Startup Time	-	-	
h	STOP TIME	Adjust the Track End Time	-	-	
i	Pitch Slider	Pitch Up / Down	-	-	