

GENERAL Functions

Button/Knob	Traktor Function
1 [Play]	Play/Pause Timecode Signal (Hybrid Mode)
2 [Cue]	Stop/Cue Timecode Signal (Hybrid Mode)
3 [Fast Search]	Fast Search Track via BeatJumps (Size via Loop Trim)
6 [Loop Trim]	Set Size for BeatJumps dec (-) & inc (+) [MOVE/CUE Mode]
7 [Effects]	AutoLoop: Size + Set [VFD (A/B) BLINK]
8 [FWD/BOTH]	Switch Browser Fullscreen/Normal (Only Browser Toggle)
9 [AutoLoop Set] [Memo] [Exit]	BeatSync (on/off) TempoSync Auto Master Mode (on/off)
12 [Time] [Title/ID3] [Display]	Snap Mode on/off Quantize Mode on/off Layout Select (switch between all Layouts)
14 [Flip] [A/B Trim] [Next Track]	SHIFT for Playmode & Browser/Tree Duplicate Deck (from A/B) / Internal Playmode [SHIFT] Set to Master / Scratch Control Playmode [SHIFT] [VFD Red Dot]
15 [Parameters]	Browse Tracks + Load / Browse Tree + Expand/Collapse [SHIFT]
16 [Playlist + Back]	Select Favorite up / down
17 [Pitch Fader]	Pitching the Spinning Platter (Hybrid Mode)
18 [Key Adjust]	Keylock on/off [VFD KEYADJ]
19 [Pitch Range] [Pitch Bend]	Pitch Range (Hybrid Mode) [Feedback LED: Beat Phase Monitor] Pitch Bending decrease (-) / increase (+)
22 [Platter Mode] [Reverse]	Phase Sync [Feedback LED: green = Master, red = Slave] Spinning Platter reverse/forward (Hybrid Mode)
25 [Disc Eject]	Jump to the Beginning of the Track

MIDI-Mapping for Denon S-3700 in Hybrid Mode with NI Traktor 2.0.2

V2.1 2011-06-14 by mclub7.de



MOVE Mode

Button/Knob	Traktor Function
4 [Echo/loop] [Flanger] [Filter]	Switch Advanced Panel to „Move“ Mode (Move) Switch Advanced Panel to „Cue“ Mode (Cue) Switch Advanced Panel to „Grid“ Mode (Grid)
6 [Loop Trim]	Set Size for BeatJumps dec (-) & inc (+)
10 [Hot Start 1] [Hot Start 2] [Hot Start 3]	BeatJump left BeatJump right n.a.
11 [CLR 1] [CLR 2] [CLR 3]	Set BeatJump Size to 1 Bar Set BeatJump Size to 4 Bars Set BeatJump Size to 16 Bars
13 [Loop A] [Loop B] [Exit/Reloop]	Loop In Loop Out Loop Active (activate/deactivate)
23 [Dump]	EQ High Kill
24 [Brake]	EQ Low Kill

MIDI-Mapping for Denon S-3700 in Hybrid Mode with NI Traktor 2.0.2

V2.1 2011-06-14 by mclub7.de



CUE Mode

Button/Knob	Traktor Function
4 [Echo/loop] [Flanger] [Filter]	Switch Advanced Panel to „Move“ Mode (Move) Switch Advanced Panel to „Cue“ Mode (Cue) Switch Advanced Panel to „Grid“ Mode (Grid)
6 [Loop Trim]	Set Size for BeatJumps dec (-) & inc (+)
10 [Hot Start 1] [Hot Start 2] [Hot Start 3]	HotCue 1 (Select/Set-Store) HotCue 2 (Select/Set-Store) HotCue 3 (Select/Set-Store)
11 [CLR 1] [CLR 2] [CLR 3]	Delete HotCue 1 Delete HotCue 2 Delete HotCue 3
13 [Loop A] [Loop B] [Exit/Re-loop]	BeatJump left 4 Bars BeatJump right 4 Bars n.a.
23 [Dump]	EQ High Kill
24 [Brake]	EQ Low Kill

MIDI-Mapping for Denon S-3700 in Hybrid Mode with NI Traktor 2.0.2

V2.1 2011-06-14 by mclub7.de



GRID&SEEK Mode

Button/Knob	Traktor Function
4 [Echo/loop] [Flanger] [Filter]	Switch Advanced Panel to „Move“ Mode (Move) Switch Advanced Panel to „Cue“ Mode (Cue) Switch Advanced Panel to „Grid“ Mode (Grid)
5 [Tap]	BPM Tapping (sets the Beatgrid if Gridlock is disabled)
6 [Loop Trim]	BPM /2 [-] / BPM x2 [+] (BPM Lock disabled)
10 [Hot Start 1] [Hot Start 2] [Hot Start 3]	Jump to Seek Position 15% of Track Jump to Seek Position 30% of Track Jump to Seek Position 50% of Track
11 [CLR 1] [CLR 2] [CLR 3]	Fast Search left Jump to Beginning of Track Fast Search right
13 [Loop A] [Loop B] [Exit/Reloop]	Move Grid Marker left (BPM Lock disabled) Move Grid Marker right (BPM Lock disabled) BPM Lock on/off
23 [Dump]	Set Grid Marker (BPM Lock disabled)
24 [Brake]	Delete Grid Marker (BPM Lock disabled)

MIDI-Mapping for Denon S-3700 in Hybrid Mode with NI Traktor 2.0.2

V2.1 2011-06-14 by mclub7.de

