

## Configuring Traktor Pro/Duo 2 for the DJ Control Steel (Windows version)

### ***1- Configuration of the MIDI channel***

From the DJ Console control panel, make sure that **MIDI channel for controls** is set to **1**.

This is very important as the profile provided is configured for the DJ Control Steel to work on this channel.

If you have multiple MIDI controllers, or would like to use the DJ Console on a different MIDI channel, you will need to modify the profile accordingly. Consult Traktor's user manual for more details.



### ***2- Audio configuration in Traktor***

As the DJ Control Steel is only a MIDI controller, you will need to configure Traktor's audio setup in order to use your sound card for playback and monitoring on separate stereo channels (Consult the user manual for more details).




### 3- Configuration of the Midi controllers in Traktor 2 Pro/Duo (Version 2.12)

a) At the bottom of the configuration menu, click the **Import** button to locate and select the **.TSI** configuration file.



b) A menu will then display the different categories that will be imported



c) In **Controller-Manager**:

- For Device, select **DJ Control Steel**
- **Generic MIDI**

- Do the same for both **In-Port** and **Out-Port**.

This menu also give you access to the various **MIDI** settings, should you wish to modify them.



## **MIDI Layout for the DJ Control Steel and Traktor 2 Pro/Duo**

**NOTE:** The terms used are those employed in Traktor

### Main Configuration:

- A-** Deck Gain
- B-** EQ (Bass/ Mid/ Treble) and EQ Kill
- C-** Scratch On/Off
- D-** Tempo Bend - Down
- E-** Tempo Bend - Up
- F-** Tempo
- G-** Seek position
- H-** Monitor Cue
- I-** Load Selected
- J-** Sync
- K-** Jog Turn
- L-** Volume Fader
- M-** Master Volume
- O-** Cue
- P-** Seek Position – **Stop** / return to beginning
- Q-** Play/Pause
- R-** X-Fader



## Scratch:



**STOP + Jog Wheel : Jog Turn (Scratch)**



## Navigation/ browser:

### Folder navigation

- **Folder:** Open Browser toggle
- **Folder** +  $\uparrow \downarrow$  : Step browsing
- **Folder** + **File**: Expand/Collapse





- **Folder** +  : Fast browsing

### Playlist navigation (Default)

- $\uparrow \downarrow$  : Step browsing
- **Files:** Open Browser toggle



- **Files** +  : Fast browsing



Loop / Cue point:

**Button 1:** Loop Size -Previous

**Button 2:** Loop Set

**Button 3:** Loop Size -Next



**Button 4:** Previous Cue/Loop

**Button 5:** Cue Set /Store

**Button 6:** Next Cue/Loop



## FX (Group)



**Button 7:** Effect 1 On

**Button 8:** Effect 2 On

**Button 9:** Effect 3 On



**Button 10:** Effect 1 Select

**Button 11:** Effect 2 Select

**Button 12:** Effect 3 Select



FX unit 1

FX Unit 2

**Effect 1 Amount**




**Effect 2 Amount**






**Effect 3 Amount**





## Midi controllers map





## Deck A



## Deck B

